

GUIDELINE

Hints for tablet operation

The following tips apply specifically to the "Samsung Galaxy Tab A 10.1" 32GB", but may work similarly with other Android tablets.




Scan QR Code to open "CM
Simply scan the following QR code with your mobile device to call up "Connected Manufacturing" without having to type in a long time.
Then log in with your Hoffmann Group Digital Service Platform login data.

Hint 1: Customize the display

The tablet settings can be used to customize the display for optimal operation. This allows the display to look completely different on the same mobile device:


Display example 1

Display at lower zoom level,
Navigation bar is displayed,
Menu bar left scrollable




Display example 2

Display at larger zoom,
Hides the navigation bar,
Menu bar completely visible on the left




Below is a list of settings that you can use to customize the display to your individual needs.

Possible display settings




Hide "**Navigation Bar**" to enlarge the visible area.

- Drag the **Quick Settings** bar down with one finger.
- Tap the **Settings** icon.
- Tap on "**Display**".
- Scroll to and tap the **Navigation bar**.
- Select "**Full Screen Gestures**".



Lock "**Landscape**" so that the display does not automatically rotate during operation or scanning.

- Drag the **Quick-Set bar** down with one finger.
- Touch **Auto rotate** to lock the landscape mode.




"**Screen zoom**" so that content is directly visible without scrolling and the font is still clearly legible.

- Use one finger to pull down the **Quick-Set Toolbar**.
- Tap the **Settings** icon.
- Tap the **Display** button.
- Tap and drag the **slider** to adjust the zoom.

Hint 2: CM „Add to home screen“


Add **CM to the home screen** of your mobile device to make it work without long typing the URL can be opened at any time with one click.



- Simply **scan the QR code** at the beginning of this document with your mobile device or open your browser and **enter the link to CM** manually once.
- Then **tap on the 3-point menu** of your browser in the top right corner.
- Select **"Add to Home Screen"**.
- Confirm with **"Add"**.
- You will then find CM as icon/app on your start screen.

Hint 3: Customize keyboard display

You have the option of setting a **"floating keyboard"** instead of the "standard keyboard" on your mobile device. This can be moved very easily by **drag & drop** to keep all input fields next to the keyboard in view at all times and thus make entries more flexible.



- Tap in an **input field** so that the standard keyboard appears.
- Then tap the fifth icon in the **upper bar** to open the selection.
- Now select **"Floating keyboard"**.


Would you also like transparency and change the size of the keyboard, tap the **Settings** icon on the keyboard.

- Tap on **"Style and layout"**.
- Tap on **"Size and transparency"** and make the desired settings.



Hint 4: Use keyboard and RFID reader simultaneously

If you use an RFID reader, you have **two sources** of input: the keyboard of your mobile device and the connected RFID reader. To use **both input sources** at the same time, you need to enable the following option in the settings of your mobile device:



- First, make sure that your **mobile device is connected to the RFID reader**.
- Pull down the **quick settings bar** with one finger.
- Tap on the **settings** icon.
- Tap on **"General management"**.
- Tap on **"Language and Input"**.
- Tap on **"On-Screen keyboard"** and activate **"Show Keyboard button"** option.